

- 1. POCKET MUST BE INSITALLED LEVEL AND PARALLEL TO WINDOW WALL.
- 2. POCKET FASTENERS MUST NOT INTERFERE WITH BRACKET LOCATIONS.



SECTION AT SHADE POCKET

SCALE: 1/2 FULL SIZE

MechoSystems Design with light."

42-03 35th Street Long Island City, NY 11101 T: +1 (718) 729-2020 F: +1 (718) 729-2941 W: mechosystems.com

DoubleShade® Hybrid Electro®/1 and Mecho®/5 Bracket

Regular Roll in #5113 Pocket with 5" Closure and Tile Support, Top Mount Drawing No. EM2-002