



POCKET INSTALLER NOTE

- 1 - POCKET MUST BE INSTALLED LEVEL AND PARALLEL TO WINDOW WALL.
- 2 - POCKET FASTENERS MUST NOT INTERFERE WITH BRACKET LOCATIONS.

1

TYPICAL SECTION

SCALE: 1/2 FULL SIZE

<p>MechoShade Systems, Inc. 42-03 35th Street Long Island City, NY 11101 Tel: 718-729-2020 Fax: 718-729-2941</p>	JOB	1			
	TITLE	REV	DATE	BY	DESCRIPTION
	ARCHITECT	DATE		JOB No.	
	DEALER	SCALE		PROPOSAL No.	
		DWN. BY	SHEET No.	OF	DWG No.